

JOMAR[®]

Manufacturers of Banners & Table Linens

DETAILED LAUNDRY PROGRAMS

100# Washing Machine

WHITE -- NOVA™ SOLID & PINTUCK

STEP	LEVEL	TEMP	TIME	CHEMICALS	NOTES
1.	HIGH	160	15 min	12 oz ALKALI 14 oz HD 1000	SUDS BATH
2.	MED	160	8 min	6 oz ALKALI 14 oz CHLORINE 7%	BLEACH "NO DRAIN"
3.	HIGH	160	6 min	4 oz ALKALI 8 OZ CHLORINE 7%	2 nd BLEACH
4.	HIGH	160	4 min		RINSE
5.	HIGH	145	3 min	COOL DOWN	RINSE
6.	HIGH	130	3 min	COOL DOWN	RINSE
7.	INTERMEDIATE EXTRACT.....2 min				
8.	HIGH	120	3 min	COOL DOWN	RINSE
9.	INTERMEDIATE EXTRACT.....2 min				
10.	MED	90	5 min	3 oz SOUR	FINAL RINSE
11.	FINAL EXTRACT MEDIUM SPEED 4 MIN.				

Note: HD 1000 is the name of the soap we use here. Ecolab has something similar which they call Turbo Lifter

- * TEMPERATURES MAY VARY 5 DEGREES.
- * TIMES MAY VARY 2 – 4 MINUTES EACH STEP

Key: Bring the temperature down slowly. If you come down too fast, you will "shock" the fabric and the wrinkles will come back after the fabric cools.